

TALBOT													
0,9 1D1	29 kW (39 PS)	1000	10/76-07/78	<b>S30197-00</b> <sup>12</sup> <sup>13</sup> 0016837800 <b>D30197-00</b> <sup>12</sup> 0003840500	<b>H05761-00</b> 0013166800 71 Ø 		<b>X05764-01</b> 55116900 Kork 	<b>N91580-00</b> <b>P76531-00</b> 0249.48	8x 	<b>X05762-01</b> 	<b>X05769-01</b> 55116500 	<b>X05763-01</b> Kork 	<b>P76119-01</b> K ← 00167744200 40x58x8 RD <b>P76310-01</b> K → 0013195100 71x88x8 LD
0,9 5C1(XV5) 5C1(XV8)	31 kW (42 PS)	SAMBA	01/81-12/85	<b>S30652-00</b> <sup>12</sup> <sup>13</sup> 95551299 <b>D30652-00</b> <sup>12</sup> 9400198589 <b>R30652-00</b> <sup>3</sup> 7910003960 <b>R30712-00</b> <sup>3</sup> 7701348178 (x4)	<b>H07125-00</b> 7910023622 74,3 Ø 1,2 mm 16 mm <b>H17125-10</b> 020322 74,3 Ø 1,4 mm 16 mm 		<b>X07128-01</b> 7910011371 	<b>N90300-00</b> <b>P76531-00</b> 0249.48	8x 	<b>X07126-01</b> 7910008467 	<b>X07129-01</b> 0304.17 	<b>P76099-11</b> K ← 0514.15 35x50x8 A SL WD FPM <b>P76321-01</b> K → 0514.14 78x100x10 A SL LD MVQ <b>P76003-01</b> N 0526.06 14x19x4,5 NBR	
1,1 E1B	40 kW (54 PS)	HORIZON	01/79-09/84	<b>S30740-00</b> <sup>12</sup> <sup>13</sup> 0003840000 <b>D30740-00</b> <sup>12</sup> 0003799700 <b>B30740-00</b> <sup>13</sup>	<b>H05910-00</b> 0013166700 76,7 Ø <b>H15910-10</b> 0209.28 76,7 Ø 1,8 mm 		<b>X05764-01</b> 55116900 Kork 	<b>N90300-00</b> <b>P76531-00</b> 0249.48	8x 	<b>X07198-01</b> 13236800 	<b>X05769-01</b> 55116500  <b>X07077-01</b> <sup>13</sup> 0016175200 	<b>E30207-00</b> 0012853300+  	<b>P76119-01</b> K ← 00167744200 40x58x8 RD <b>P76310-01</b> K → 0013195100 71x88x8 LD
1,1 XW7	37 kW (50 PS)	SAMBA	01/81-06/86	<b>S31588-00</b> <sup>12</sup> <sup>13</sup> 95551299 <b>D31588-00</b> <sup>12</sup> 0197.74 <b>B31588-00</b> 0197.76 <b>R30712-00</b> <sup>3</sup> 7701348178 (x4)	<b>H00687-00</b> 0209.G8 76 Ø 1,2 mm 16 mm <b>H10687-10</b> 0203.23 76,3 Ø 1,4 mm 16 mm 		<b>X07128-01</b> 7910011371 	<b>N90300-00</b> <b>P76531-00</b> 0249.48	8x 	<b>X07126-01</b> 7910008467 	<b>X07129-01</b> 0304.17 	<b>P76099-11</b> K ← 0514.15 35x50x8 A SL WD FPM <b>P76321-01</b> K → 0514.14 78x100x10 A SL LD MVQ	
1,1 3E1	37-41 kW (50-56 PS)	1100	10/68-01/80	<b>S30872-00</b> <sup>12</sup> <sup>13</sup> 16837800 <b>D30872-00</b> <sup>12</sup> 0017476000	<b>H05910-00</b> 0013166700 76,7 Ø <b>H15910-10</b> 0209.28 76,7 Ø 1,8 mm 		<b>X05764-01</b> 55116900 Kork 	<b>N90300-00</b> <b>P76531-00</b> 0249.48	8x 	<b>X07198-01</b> 13236800 	<b>X05769-01</b> 55116500 	<b>E30207-00</b> 0012853300+  	<b>P76119-01</b> K ← 00167744200 40x58x8 RD <b>P76310-01</b> K → 0013195100 71x88x8 LD

TALBOT															
Ltr.															
1,2 129 D	65 kW (88 PS)	SAMBA	01/83-10/86	S30775-00 <sup>(12)</sup> <sup>(13)</sup> 0197.18 D30775-00 <sup>(12)</sup> 0197.17 R30712-00 <sup>(3)</sup> 7701348178 (x4)	H00687-00 0209.G8 76 Ø 1,2 mm 16 mm H10687-10 0203.23 76,3 Ø 1,4 mm 16 mm			X07128-01 7910011371	N90300-00 P76531-00 0249.48	8x	X07565-01 7910030796		X07126-01 7910008467	X07129-01 0304.17	P76099-11 K ← 0514.15 35x50x8 A SL WD FPM P76321-01 K → 0514.14 78x100x10 A SL LD MVQ P76003-01 N 0526.06 14x19x4,5 NBR
1,3 G1E/ECO 1G1 2G1 2G1-BTC 3G4 6G1D	40-62 kW (54-84 PS)	HORIZON MATRA BAGHEERA 1000 1100 1307	10/72→	S30741-00 <sup>(12)</sup> <sup>(13)</sup> 0017477200 D30741-00 <sup>(12)</sup> 0016806800	H06900-00 13238800 78,5 Ø 1,2 mm			X05764-01 55116900 Kork	N90300-00 P76531-00 0249.48	8x	X05917-01 0055204500 X07198-01 13236800		X05769-01 55116500 X07077-01 <sup>(A)</sup> 0016175200	E30207-00 0012853300+	P76119-01 K ← 00167744200 40x58x8 RD P76310-01 K → 0013195100 71x88x8 LD
1,4 XY 6B XY7 XY8	44-58 kW (60-79 PS)	SAMBA	01/81→	S30776-00 <sup>(12)</sup> <sup>(13)</sup> 0197.20 D30776-00 <sup>(12)</sup> 0197.19 B30776-00 <sup>(13)</sup> R30712-00 <sup>(3)</sup> 7701348178 (x4)	H00687-00 0209.G8 76 Ø 1,2 mm 16 mm H10687-10 0203.23 76,3 Ø 1,4 mm 16 mm			X07128-01 7910011371	N90300-00 P76531-00 0249.48	8x	X07565-01 7910030796		X07126-01 7910008467	X07129-01 0304.17	P76099-11 K ← 0514.15 35x50x8 A SL WD FPM P76321-01 K → 0514.14 78x100x10 A SL LD MVQ P76003-01 N 0526.06 14x19x4,5 NBR
1,4 Y1B/ECO Y2 6G1D/VP	47-63 kW (65-85 PS)	HORIZON	01/75→	S30741-00 <sup>(12)</sup> <sup>(13)</sup> 0017477200 D30741-00 <sup>(12)</sup> 0016806800	H06900-00 13238800 78,5 Ø 1,2 mm			X05764-01 55116900 Kork	N90300-00 P76531-00 0249.48	8x	X05917-01 0055204500 X07198-01 13236800		X05769-01 55116500 X07077-01 <sup>(A)</sup> 0016175200	E30207-00 0012853300+	P76119-01 K ← 00167744200 40x58x8 RD P76310-01 K → 0013195100 71x88x8 LD
1,6 J1 J2	65 kW (88 PS)	SOLARA	02/80-06/81	S30117-00 <sup>(12)</sup> <sup>(13)</sup> 0017596800 D30117-00 <sup>(12)</sup> 0017570500	H07648-00 9751113480 82 Ø			X05764-01 55116900 Kork	N90300-00 P76531-00 0249.48	8x	X07198-01 13236800		X05769-01 55116500 X07077-01 <sup>(A)</sup> 0016175200	E30207-00 0012853300+	P76119-01 K ← 00167744200 40x58x8 RD P76310-01 K → 0013195100 71x88x8 LD
1,8 7S2	74 kW (101 PS)	1610 180	09/76-12/82	S30644-00 <sup>(12)</sup> <sup>(13)</sup> 0004509200 D30644-00 <sup>(12)</sup> 0004509600	H04615-00 0013628100 91 Ø			X04620-01 4084900 Kork	N91480-00 P76546-00	8x	X04619-01		X04618-01 0004090400 X07077-01 <sup>(A)</sup> 0016175200	X04631-01 4066800 Kork	P76119-01 K ← 00167744200 40x58x8 RD

TALBOT												
1,9 XUD9	47-48 kW (64-65 PS)	HORIZON D	07/82-06/86	<p><b>S30527-00</b> ⑫ ⑬ 0197.H5</p> <p><b>D30527-00</b> ⑫</p> <p><b>B30527-00</b> ⑬</p>	<p><b>H05876-00</b> 0209.S5 1,36 mm 1</p> <p><b>H05876-10</b> 0209.S6 1,4 mm 2</p> <p><b>H05876-20</b> 0209.S7 1,44 mm 3</p> <p><b>H07781-00</b> 0209.K0 1,58 mm</p> <p><b>H15876-30</b> 0209.S8 1,48 mm 4</p> <p><b>H15876-40</b> 0209.S9 84 Ø 1,53 mm 5</p> <p><b>H17781-10</b> 1,7 mm</p>	<p><b>T08280-00</b> 9301030680 (10x)</p>	<p><b>X07796-01</b> 9301024280</p>	<p><b>N90300-00</b> <b>P76531-00</b> 0249.48</p>	<p><b>X55498-01</b> 0348.99</p> <p><b>X55499-01</b> 0348.98</p>	<p><b>X07782-01</b> 9301040280</p> <p><b>X03013-01</b> ⚠</p>	<p><b>X07793-01</b> 0304.34</p>	<p><b>P76151-01 K</b> ← 0326.12 42x62x7 A RD FPM</p> <p><b>P76386-01 K</b> → 90x110x7 A SL LD FPM</p> <p><b>P76099-11 N</b> 2x 0514.15 35x50x8 A SL WD FPM</p>
1,9 XUD9A	51 kW (69 PS)	EXPRESS 1000 -1500 EXPRESS 1000 -1800	07/87-10/90	<p><b>S31582-00</b> ⑫ ⑬ 0197.H5</p> <p><b>D31582-00</b> 9400197379</p> <p><b>B31582-00</b> ⑬</p>	<p><b>H05876-00</b> 0209.S5 1,36 mm 1</p> <p><b>H05876-10</b> 0209.S6 1,4 mm 2</p> <p><b>H05876-20</b> 0209.S7 1,44 mm 3</p> <p><b>H15876-30</b> 0209.S8 1,48 mm 4</p> <p><b>H15876-40</b> 0209.S9 84 Ø 1,53 mm 5</p>	<p><b>T08280-00</b> 9301030680 (10x)</p>	<p><b>X07796-01</b> 9301024280</p>	<p><b>N90300-00</b> <b>P76531-00</b> 0249.48</p>	<p><b>X51239-01</b> ⑦</p>	<p><b>X03013-01</b> ⚠</p>	<p><b>X07793-01</b> 0304.34</p>	<p><b>P76151-01 K</b> ← 0326.12 42x62x7 A RD FPM</p> <p><b>P76386-01 K</b> → 90x110x7 A SL LD FPM</p> <p><b>P76099-11 N</b> 0514.15 35x50x8 A SL WD FPM</p>
2,0 XN1TA XN1TACP Kat. (78-98 PS)	57-72 kW (78-98 PS)	EXPRESS 1000 -1500 EXPRESS 1000 -1800	07/82→	<p><b>D30777-00</b> ⑫</p>	<p><b>H02760-00</b> 90,2 Ø 1,2 mm</p>	<p><b>T02666-00</b> →06/85</p> <p><b>T02760-00</b> 07/85-04/89</p> <p><b>T01025-00</b> 05/89→</p>	<p><b>X04835-01</b> NBR</p>	<p><b>N90300-00</b> <b>P76531-00</b> 0249.48</p>	<p><b>X03615-01</b> <b>X07480-01</b></p>	<p><b>X04833-01</b></p>	<p><b>X54253-01</b> Kork</p>	<p><b>P76150-01 K</b> ← 0514.11 42x60x8 A RD FPM</p>
2,1 5N2	85 kW (116 PS)	MURENA TAGORA	06/80-07/84	<p><b>S30645-00</b> ⑫ ⑬ 13516600</p> <p><b>D30645-00</b> ⑫ 0013516400</p> <p><b>B30645-00</b> ⑬</p>	<p><b>H04616-00</b> 0013627500 94,5 Ø</p>		<p><b>X04620-01</b> 4084900 Kork</p>	<p><b>N91480-00</b> <b>P76546-00</b></p>	<p><b>X04619-01</b></p>	<p><b>X04618-01</b> 0004090400</p> <p><b>X07077-01</b> ⚠ 0016175200</p>	<p><b>X04631-01</b> 4066800 Kork</p>	

TALBOT																						
2,3 XD2S	59 kW (80 PS)	TAGORA TD	08/81-12/87	A30243-00 <sup>12</sup> <sup>14</sup> 0197.25  S30243-00 <sup>13</sup> D30243-00 <sup>12</sup> 0197.08 	H06656-00 0209.55 1,58 mm 2 H16656-10 0209.50 96 Ø 1,7 mm 3 					X06833-01 7932564008 NBR 			X08241-01 	2x			X07092-01 	2x	X08253-01 		P76150-01 K ← 0514.11 42x60x8 A RD FPM X08246-01 K → 1227968610	2x
2,5 CRD93	54 kW (73 PS)	EXPRESS 1000 -1500 EXPRESS 1000 -1800	07/82-10/94	D30253-00 <sup>12</sup>	H06666-00 96.3 Ø 	T06345-00 	X01015-01 										X00881-01 	4x			P76314-01 K ← 75x90x11,5 A SL RD FPM	
2,5 CRD93LS	70 kW (95 PS)	EXPRESS 1000 -1500 EXPRESS 1000 -1800	06/87-10/94	D31052-00 <sup>12</sup>	H06345-00 95,6 Ø 	T06345-00 	X01015-01 	N90300-00 P76531-00 0249.48	8x	X00837-01 	4x						X00881-01 	4x			P76314-01 K ← 75x90x11,5 A SL RD FPM	
2,6 9L6	122 kW (166 PS)	TAGORA	08/81-10/83	S30758-00 <sup>12</sup> <sup>13</sup> 0197.75 D34758-00 <sup>12</sup> D35758-00 <sup>12</sup> L 0198.67 B30758-00 <sup>13</sup> R30758-00 <sup>3</sup>	H07627-00 R 7910245291 90,2 Ø  H07628-00 L 7910045585 90,2 Ø 	T08263-00 	X07629-01 R 7910245546  X07630-01 L 7910246555 	N91210-00 P76531-00 0249.48	12x	X07636-01 	6x	X07777-01 7910245243 	2x				X07634-01 43018000 	2x	X06861-01  X07633-01 0123.19 		P76152-01 K ← 0514.21 42x62x10 A SL RD FPM P76345-01 K → 80x100x13 A SL LD MVQ P76128-11 N 32x45x8 A LD FPM	
3,9 1D1	29 kW (39 PS)	1000	10/61-09/75	S30197-00 <sup>12</sup> <sup>13</sup> 0016837800 D30197-00 <sup>12</sup> 0003840500	H05761-00 0013166800 71 Ø 		X05764-01 55116900 Kork 	N91580-00 P76531-00 0249.48	8x	X05762-01 							X05769-01 55116500 		X05763-01 Kork 		P76119-01 K ← 00167744200 40x58x8 RD P76310-01 K → 0013195100 71x88x8 LD	