

MITSUBISHI													
Ltr.													
0,7 3B20	38 kW (52 PS)	i	01/10→	<b>S40473-00</b> <sup>12</sup> <sup>13</sup> <sup>38</sup>	<b>H40473-00</b> 	<b>T81769-02</b> 1005A425 (8x) 	<b>X83380-01</b> 1035A486 	<b>N92114-00</b> MR984262 (12x) <b>P76707-00</b> MR984262	12x 	<b>M89966-00</b> 1540A089 (3x) 	<b>X82387-01</b> 1555A292 	<b>70-31414-10</b> 	<b>P77685-01 K</b> ← 1052A266 27x40x6,5 AB RD FPM <b>P93212-01 K</b> → 1052A210 85
0,7 3B20 T	42-47 kW (57-64 PS)	i	01/06→	<b>S40472-00</b> <sup>12</sup> <sup>38</sup>	<b>H40472-00</b> 1005A914 	<b>T81769-02</b> 1005A425 (8x) 	<b>X83380-01</b> 1035A486 	<b>N92114-00</b> MR984262 (12x) <b>P76707-00</b> MR984262	12x 	<b>M89966-00</b> 1540A089 (3x) 	<b>X82387-01</b> 1555A292 	<b>70-31414-10</b> 	<b>P77685-01 K</b> ← 1052A266 27x40x6,5 AB RD FPM <b>P93212-01 K</b> → 1052A210 85

Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.	Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No.
H40472-00 H40473-00 M89966-00 N92114-00 P76707-00 P77685-01 P93212-01 <b>NEW</b> S40472-00 S40473-00 T81769-02 <b>NEW</b> X82387-01 X83380-01 70-31414-10									