

| HONDA | | | | | | | | | | | | |
|--------------------|--|--------|--|---|---|---|---|---|--|---|----------------------------------|--|
| Ltr. | | | | | | | | | | | | |
| 2,2 N22B1 N22B2 | 110-132 kW (150-180 PS) ACCORD DTEC | 07/08→ | | | | | | | | | | |
| | | | D90201-00 ¹² | H84850-00 12251-RL0-G01 86 Ø 1,25 mm MLS H84850-10 12252-RL0-G01 86 Ø 1,3 mm MLS H84850-20 12253-RL0-G01 86 Ø 1,35 mm MLS H84850-30 12254-RL0-G01 86 Ø 1,4 mm MLS H84850-40 12255-RL0-G01 86 Ø 1,45 mm MLS | T84840-00 90005-RBD-E01 (10X) | V90179-00 12030-RL0-G00 | N93047-00 12210-PZ1-004 (8x) +12211-PZ1-004 (8x) | X90207-01 17105-RL0-G01 | | X90206-01 18115-RL0-G01 | 70-31414-10 | P77567-01 K ← 91212-RBD-E01 43x58x7 A SL RD ACM P77568-01 K → 91214-RBD-E01 87x104x10 A SL LD MVQ |
| 2,2 N22B3 | 110 kW (150 PS) CR-V | 01/07→ | D90201-00 ¹² 01/10→ | H84850-00 12251-RL0-G01 86 Ø 1,25 mm MLS 01/10→ H84850-10 12252-RL0-G01 86 Ø 1,3 mm MLS 01/10→ H84850-20 12253-RL0-G01 86 Ø 1,35 mm MLS 01/10→ H84850-30 12254-RL0-G01 86 Ø 1,4 mm MLS 01/10→ H84850-40 12255-RL0-G01 86 Ø 1,45 mm MLS 01/10→ | T84840-00 90005-RBD-E01 (10X) 01/10→ | V90179-00 12030-RL0-G00 01/10→ | N93047-00 12210-PZ1-004 (8x) +12211-PZ1-004 (8x) 01/10→ | X90207-01 17105-RL0-G01 01/10→ | | X90206-01 18115-RL0-G01 01/10→ | 70-31414-10 01/10→ | P77567-01 K ← 91212-RBD-E01 43x58x7 A SL RD ACM 01/10→ P77568-01 K → 91214-RBD-E01 87x104x10 A SL LD MVQ 01/10→ |

| Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. | Ref. GLASER GLASER-Nr. GLASER-No. Réf. GLASER Rif. GLASER Glaser No. |
|---|---|---|---|---|---|---|---|---|---|
| D90201-00 NEW | | | | | | | | | |
| H84850-00 NEW | | | | | | | | | |
| H84850-10 NEW | | | | | | | | | |
| H84850-20 NEW | | | | | | | | | |
| H84850-30 NEW | | | | | | | | | |
| H84850-40 NEW | | | | | | | | | |
| N93047-00 | | | | | | | | | |
| P77567-01 | | | | | | | | | |
| P77568-01 | | | | | | | | | |
| T84840-00 NEW | | | | | | | | | |
| V90179-00 | | | | | | | | | |
| X90206-01 | | | | | | | | | |
| X90207-01 | | | | | | | | | |
| 70-31414-10 | | | | | | | | | |