

ISUZU											
Ltr.											
1,6 G161Z	74 kW (101 PS)		<b>S37231-00</b> <sup>(12)</sup> <sup>(13)</sup> 94219639 <b>D37231-00</b> <sup>(12)</sup> 94219641	<b>H80912-00</b> 94216870 82,5 Ø 		<b>X83208-01</b> 94200715 	<b>N90300-01</b> <b>P76849-00</b> 8x		<b>M37906-00</b> 94207284 	<b>X54875-01</b> 94204431 	
1,6 4XE1-UW	97-103 kW (132-140 PS)		<b>S40024-00</b> <sup>(12)</sup> <sup>(13)</sup> 894331-5322 <b>D40024-00</b> <sup>(12)</sup> 94331533	<b>H40024-00</b> 81 Ø 		<b>X83258-01</b> 94360527 	<b>N92012-01</b> 894470-9460 (16x)	<b>X89688-01</b> 94437058 	<b>X82214-01</b> 94457315 		<b>P77665-01</b> K → 8-94327063-0 87x100x8,5 B SL LD MVQ <b>P77605-01</b> N 8-94215220-0 30x45x8 A SL RD MVQ
1,7 17 D 4EE1 OHC	44 kW (60 PS)		<b>S31177-00</b> <sup>(12)</sup> <sup>(13)</sup>  <b>D31177-00</b> <sup>(12)</sup> 	<b>H02839-00</b> 1,45 mm MLS Mot.→320552 <b>H12839-10</b> 1,5 mm 1 MLS Mot.→320552 <b>H22839-20</b> 80 Ø 1,55 mm 2 MLS Mot.→320552 	<b>T07916-00</b> 	<b>X07918-01</b> 	<b>N93029-00</b>	<b>X07912-01</b> 	<b>X07917-01</b> 	<b>X07944-01</b> 	<b>P76136-01</b> K ← 40x52x6 A SL RD ACM <b>P76373-01</b> K → 8-94471619-0 87x100x8 A SL LD ACM <b>P76136-01</b> N 40x52x6 A SL RD ACM
1,9 C190	40 kW (54 PS)		<b>D80914-00</b> <sup>(12)</sup> 94030182	<b>H80914-00</b> 511141-0731 87,5 Ø MLS 		<b>X83201-01</b> 511173-0170 	<b>N92007-00</b> 512569-0060 (8x)		<b>X89810-01</b> <sup>(7)</sup> 894145-1480 	<b>X89846-01</b> <sup>(11)</sup> 94028764 	
2,0 G200Z	58 kW (79 PS)	CAMPO	06/85-12/88	<b>D37232-00</b> <sup>(12)</sup> 894255-4551	<b>H80913-00</b> 94213809 88 Ø 	<b>X83208-01</b> 94200715 	<b>N90300-01</b> <b>P76849-00</b> 8x	<b>X89622-01</b> 2x 94210402 	<b>M37906-00</b> 94207284 	<b>X54875-01</b> 94204431 	<b>P77499-01</b> K ← 8-97049145-0 50x68x9/14 A SL RD FPM <b>P77519-01</b> K → 9-09924449-0 82x105x13 A SL LD MVQ
2,0 4ZC1 4ZC1-T	52-110 kW (71-150 PS)	ASKA CAMPO MIDI PIAZZA Turbo	01/83→	<b>S50082-00</b> <sup>(12)</sup> <sup>(13)</sup> 894124-6250 <b>D50082-00</b> <sup>(12)</sup> 587810-3360	<b>H50082-00</b> 849224-3131 89 Ø 	<b>V37947-00</b> 894214-9850 	<b>N90300-01</b> <b>P76849-00</b> 8x	<b>X89623-01</b> 894111-6490 	<b>X82148-01</b> 894246-1091 	<b>X54876-01</b> 894235-2881 	<b>P76117-01</b> K ← 8-94214912-0 40x56x7 A SL RD MVQ <b>P77358-01</b> K → 8-97071561-1 95x118x13 A SL LD FPM <b>P77605-01</b> N 8-94215220-0 30x45x8 A SL RD MVQ

ISUZU														
2,2 C223 C223T	39-53 kW (53-72 PS)	CAMPO D TROOPER D TROOPER TD	01/83-12/91	<b>S80915-00</b> ⑫ ⑬ 894167-7800 <b>D80915-00</b> ⑫ 894248-8300	<b>H80915-00</b> 894156-0780 89 Ø MLS 		<b>X83201-01</b> 511173-0170 	<b>N92007-00</b> 512569-0060 (8x) 	<b>X89810-01</b> ⑦ 894145-1480 	<b>X54877-01</b> 511367-0040  <b>X89846-01</b> ⑩ 94028764 	<b>P77504-01</b> K ← 65x84x9 A SL RD NBR <b>P77519-01</b> K → 9-09924449-0 82x105x13 A SL LD MVQ <b>P76143-01</b> N 42x55x9 RD ACM			
2,2 4FD1	45 kW (61 PS)	MIDI D	09/88→	<b>S50081-00</b> ⑫ ⑬ 894438-3150 <b>D50081-00</b> ⑫ 894438-3180	<b>H50081-00</b> 894124-8800 88 Ø 		<b>X83209-01</b> 94239140 	<b>N90300-01</b> <b>P76849-00</b> 	<b>X89624-01</b> 94221022 8x 	<b>X82149-01</b> 94221025 	<b>X54878-01</b> 94226564 	<b>P76117-01</b> K ← 8-94214912-0 40x56x7 A SL RD MVQ <b>P77358-01</b> K → 8-97071561-1 95x118x13 A SL LD FPM <b>P77601-01</b> N 5-09625053-1 28x47x8 A SL RD MVQ		
2,3 4ZD1	66 kW (90 PS)	CAMPO TROOPER	11/85-12/91	<b>S80916-00</b> ⑫ ⑬ 587810-3433 <b>D80916-00</b> ⑫ 94335884	<b>H80916-00</b> 94324053 91 Ø 		<b>V37947-00</b> 894214-9850 	<b>N90300-01</b> <b>P76849-00</b> 	<b>X89625-01</b> 894146-2490 8x 	<b>X82148-01</b> 894246-1091 	<b>X54879-01</b> 894152-7890 	<b>P76117-01</b> K ← 8-94214912-0 40x56x7 A SL RD MVQ <b>P77358-01</b> K → 8-97071561-1 95x118x13 A SL LD FPM <b>P77605-01</b> N 8-94215220-0 30x45x8 A SL RD MVQ		
2,4 C240	44-55 kW (60-75 PS)			<b>S80914-00</b> ⑫ ⑬ 587810-2082 <b>D80914-00</b> ⑫ 94030182	<b>H80914-00</b> 511141-0731 87,5 Ø MLS 		<b>X83201-01</b> 511173-0170 	<b>N92007-00</b> 512569-0060 (8x) 	<b>X89810-01</b> ⑦ 894145-1480 	<b>X54877-01</b> 511367-0040 	<b>P77499-01</b> K ← 8-97049145-0 50x68x9/14 A SL RD FPM <b>P77519-01</b> K → 9-09924449-0 82x105x13 A SL LD MVQ			
2,4 KB240	94 kW (128 PS)			<b>S80856-00</b> ⑫ ⑬ 92066630 +92061971 +93282665 <b>D80856-00</b> ⑫ 92066630	<b>H80856-00</b> 93282665 90 Ø MLS 		<b>X53298-01</b> 90467661 Kork 	<b>N92310-00</b> 90215296 (8x) 	<b>X07923-01</b> 90353579 	<b>X08205-01</b> 90409644 	<b>70-31414-10</b> 	<b>P76085-01</b> K ← 31x50x8 A SL RD FPM <b>P76384-01</b> K → 90x104x9/11 AB SL LD FPM <b>P76095-01</b> N 35x48x7 A SL RD MVQ		
2,5 4JA1	55 kW (75 PS)	CAMPO D	01/83-12/90	<b>S37206-00</b> ⑫ ⑬ 894319-3700 <b>D37206-00</b> ⑫ 894319-3760	<b>H07746-00</b> 894433-7330 1,6 mm 1 <b>H17746-10</b> 1,65 mm 2 <b>H27746-20</b> 94 Ø 1,7 mm 3 		<b>V36002-00</b> 	<b>N92007-00</b> 512569-0060 (8x) 	<b>X89162-01</b>  <b>X89163-01</b> ⑩ 	<b>X81927-01</b> 	<b>X54880-01</b> 894152-4521 	<b>P76467-01</b> K ← 8-97049145-0 50x68x9 A SL RD FPM <b>P77358-01</b> K → 8-97071561-1 95x118x13 A SL LD FPM <b>P76117-01</b> N 8-94214912-0 40x56x7 A SL RD MVQ		

ISUZU															
Ltr.															
2,5 4JK1-TC	100 kW (136 PS)	D-MAX D D-MAX DITD	10/06→	<b>S38285-00</b> <sup>12</sup> <sup>13</sup>  <b>D38284-00</b> <sup>12</sup> 	<b>H40588-00</b> 8-98135953-0 +8-97328828-2 97 Ø 1 <b>H40588-10</b> 8-98135954-0 +8-97331631-2 97 Ø 2 <b>H40588-20</b> 8-98135955-0 +8-97331632-2 97 Ø 3 										
2,6 4ZE1	85-90 kW (116-122 PS)	PICK UP TROOPER	11/86-12/91	<b>S80917-00</b> <sup>12</sup> <sup>13</sup> 894335-9393 <b>D80917-00</b> <sup>12</sup> 894312-5881	<b>H80917-00</b> 894174-2790 94 Ø 										
2,8 4JB1	42-74 kW (57-101 PS)			<b>S37206-00</b> <sup>12</sup> <sup>13</sup> 894319-3700 <b>D37206-00</b> <sup>12</sup> 894319-3760	<b>H07746-00</b> 894433-7330 1,6 mm 1 <b>H17746-10</b> 1,65 mm 2 <b>H27746-20</b> 94 Ø 1,7 mm 3 	<b>T09003-00</b> 									
2,8 4JB1T 4JB1-TC	67-85 kW (91-116 PS)	TROOPER TD	10/87→	<b>S36002-00</b> <sup>12</sup> <sup>13</sup>  <b>D36002-00</b> <sup>12</sup> 	<b>H07746-00</b> 894433-7330 1,6 mm 1 <b>H17746-10</b> 1,65 mm 2 <b>H27746-20</b> 94 Ø 1,7 mm 3 	<b>T09003-00</b> 									

ISUZU													
3,0 4JH1-TC	96 kW (131 PS)	D-MAX DITD	05/02→										
Ltr.			1										
3,0 4JJ1-TC	120 kW (163 PS)	D-MAX D-MAX D	01/07→										
Ltr.													
3,0 4JX1	118 kW (160 PS)	TROOPER DTI	05/98→										
Ltr.													
3,1 C4JG 4JG2 T 4JG2TC	84 kW (114 PS)	TROOPER TD	08/91-07/98										
Ltr.													

ISUZU													
Ltr.													
3,5 6VE1	158 kW (215 PS)	TROOPER V6	04/00→		<b>H80090-00 R</b> 94,5 Ø 			<b>N92008-00</b> <b>P76814-00 ES</b> 12x <b>P76815-00 AS</b> 12x	<b>X89165-01</b> 8-97237538-0 2x 		<b>X52449-01</b> 8-97148717-0 2x 	<b>P77693-01 K</b> → 95x118x10 B SL LD FPM	
3,9 4BD1	78 kW (106 PS)			<b>S40081-00</b> ⑫ ⑬ <b>D40081-00</b> ⑫	<b>H40081-00</b> 104,7 Ø 1,55 mm MLS 		<b>V37996-00</b> 	<b>N93052-00</b>	<b>M37916-00</b> 		<b>X82296-01</b> 2x 	<b>X54914-01</b> 	<b>P77694-01 K</b> ← 60x82x10 A SL RD FPM <b>P77695-01 K</b> → 100x135x15 A METALL LD MVQ <b>P77696-01 K</b> → 105x135x14,7 AB SL FILZ LD FPM
5,8 6BD1	110 kW (150 PS)			<b>S40082-00</b> ⑫ ⑬ 1-87810363-2 <b>D40082-00</b> ⑫	<b>H40082-00</b> 107 Ø 1,55 mm MLS 		<b>V37997-00</b> 	<b>N93052-01</b>	<b>X89776-01</b> 		<b>X82296-01</b> 3x 	<b>X54915-01</b> 	<b>P77694-01 K</b> ← 60x82x10 A SL RD FPM <b>P77695-01 K</b> → 100x135x15 A METALL LD MVQ <b>P77696-01 K</b> → 105x135x14,7 AB SL FILZ LD FPM